



HEAVY DUTY CV AXLES – Pontiac GTO
Part # CV001

1. Lift vehicle and support with stands under the cradle allowing the rear wheels to hang. Set emergency brake.
2. Using a 5/16" or 8mm Allen head socket, remove all 24 bolts that attach the CV shaft; there are 6 at each end of the shaft. Remove the CV shafts.
3. Once the shafts have been removed, remove the dust end caps from each end. It is necessary to replace the dust caps from the BMR HD CV's with the dust caps from the OE CV's. (See Image 1 for identifying the proper end caps). Failure to do this will not allow the CV's to mate properly with their hubs.
4. Apply blue Loctite to the threads of the new mounting hardware and re-install the new CV shafts. It may be necessary to lift the wheels in order to get the bolts started.
5. Torque all 24 bolts to 45 ft/lbs.
6. Lower vehicle.



WWW.BMRFABRICATION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.